

POWER LOSS GATE UP - RESET HELP


This electric gate is composed of a motor with an absolute encoder. If the gate is in up position and you are experiencing a power loss (due to a power failure or if you switched off the gate system), the system will declare an error after next power and the gate won't operate.

Because last recorded gate position before power loss (Up) is different than actual position (Down)

if you open the panel of the Prostart control box, you should see on the bottom left display this Fault : F2074



PROCEDURE TO RESET THE SYSTEM



After that, you can use the gate as usual again. We recommend to switch off the system only when the gate is in down position to protect the system.